## Radiology Compliance Branch RADIATION PROTECTION SECTION



Division of Health Service Regulation • N.C. Department of Health and Human Services

## **CABINET X-RAY INSPECTION CHECKLIST**

Security Screening Units (mail, baggage), Industrial OC Cabinets and Medical Specimen Cabinets

| Security of coming of the (main, suggested in the control of coming of the control of the contro |
|--|
| North Carolina Regulations For Protection Against Radiation <u>10A NCAC 15</u> rule references shown in bracke <b>General Documents:</b> Waivers on file (if applicable) [.0108(a)]  |
| Records of Receipt / Transfer each radiation device [.0115] Current Notice of Registration [.0209] [.1002(a)(2)] Current State Regulations [.1002(a)(1)] Notice to Employees [.1002(c)] (posted in restricted area)  |
| Operating Requirements / Radiation Protection Program  Manufacturer's manual and instructions (technical, safety and maintenance schedule)  [.0117]; [21CFR1020.40(c)(9)(i)]  Operating requirements [.0805]; [.1002(a)(3)]  Current copy of the radiation protection program [.1603(a)]   |
| Labels  ☐ Identification Label (Manufacturer/date) [.0117]; [21CFR1010.3] ☐ The insertion of any part of the human body through any port into the primary beam shall not be possible (Examples: guards / drapes / sensors) [.0117]; [21CFR1020.40(c)(3)(i)] ☐ "Caution: X-Rays Produced When Energized" (located on control) [.0117]; [21 CFR 1020.40(c)(8) (ii)] ☐ "Caution: Do Not Insert Any Part of the Body When System is Energized-X-ray Hazard" (located on each port) [.0117]; [21CFR 1020.40(c)(8)(ii)]  |
| Warning Lights [.0803(k)(l)] [.0117]; [21CFR1020.40(c)(6)(iii)]  |
| <ul> <li>□ Labeled: "X-Ray On"</li> <li>□ Located: Near any switch, that energizes tube or conspicuously located near source / beam(s)</li> <li>□ Visible: From all instrument access areas</li> <li>□ Activates: When energized</li> </ul>  |
| Area Requirements [.0804(c)]  CAUTION- X-RAY EQUIPMENT" posted at each area of use or room   |
| Safety Interlocks and Security:  Safety interlocks on each door (2 req.)[.0117];[21CFR1020.40(c)(4)(i)]  Access Panel interlock functioning (1 req.) [.0117]; [21 CFR 1020.40(c)(4)(ii)]  Key-actuated control [.0117]; [21 CFR 1020.40(c)(6)(i)]  Unit security [.1622]   |
| Records:  Training documentation of person responsible for radiation protection [.0203(b)(3)]  Survey reports: [.0804(b)]; [.1613]; [.1637]  Within 30 days of initial operation Prior to use following any change in initial arrangement Prior to use following maintenance  Annual testing for proper operation of safety devices (interlocks/shutters/warning lights) [.0805] (effective 10/1/15)  Operating and emergency procedures training documentation records [.0806 (a)(2)] Annual radiation protection program review by registrant [.1603(c)]; [.1636]  |
| Personnel monitoring and exposure records [.1614]; [.1640]  *See specific requirements in 21CFR 1020.40 for cabinets that admit humans*  |

1645 Mail Service Center - Raleigh, North Carolina 27699-1600 Phone: (919) 814-2250 https://radiation.ncdhhs.gov/

Cabinet X-Ray Inspection Checklist Rev.5/8/18